



HOW TO CREATE AN **ABOVE GROUND PAVER POND**

ITEMS YOU WILL NEED:

- 20-Gallon Rigid Liner
- TotalPond® Complete Filter Kit With Pump
- 30-40 Paver Stones
- Chisel And Hammer
- Construction Adhesive
- Spitter (Optional)
- 1/2 in. ID Tubing (Optional)



Step 1: Place the rigid liner in the desired location and mark where the wall blocks should rest. Place the base row 6 in. away from the bottom of the liner.

Tip! To prepare the base row on a solid surface, the rear "lips" of the block must be removed by striking them with a sledgehammer (approx. 10 stones).



Step 2: Begin building the next tier of the pond wall. Each block has a "lip" located on the back of the stone. This lip creates a locking effect. When placing the lip down, make sure it is centered over the gap of the bottom tier. Repeat step three for the third and fourth tiers.

Tip! The seams should not line up when creating the additional tiers.



Step 3: Add Complete Filter Kit with Pump. Fill the rigid liner with water to 2 in. below the top of the liner.

Optional: Add a spitter using the diverter valve on the Complete Filter Kit with Pump and 1/2 in. ID tubing.

