



## HOW TO BUILD A MEDIUM POND

### ITEMS YOU WILL NEED:

- 10 x 13 ft. PVC Pond Liner
- TotalPond® 330 GPH Pond Pump
- TotalPond® Universal Pump Filter Box
- TotalPond® Large Nozzle Kit
- TotalPond® Pond and Landscape LED Lights
- TotalPond® Chlorine Remover Plus
- Rocks and mulch for landscaping
- Rope or string
- Shovel



**Step 1:** Mark the desired location of the pond with rope or string and dig the hole. Leave a mound of dirt along the perimeter of the pond.



**Step 2:** Cover the entire area with the liner. The liner should extend over the sides of the pond by 10-12 in.



**Step 3:** Cover the liner with rock including the 10-12 in. around the perimeter; leave a small area void of rock to run the cords outside the pond. Trim away excess liner.



**Step 4:** Add pump with assembled nozzle kit and lights to pond. Position the lighting and run the power cord to the outside of the pond; cover cords with rock.



**Step 5:** Fill pond with water. Add Chlorine Remover before adding any fish or plants to water; it removes chlorine, chloramines, and heavy metals from water.



**Step 6:** Sit back and enjoy your new creation!