



HOW TO CREATE A TALL MODERN FOUNTAIN

ITEMS YOU WILL NEED:

- TotalPond® Container Fountain Kit with Light
- Tall, Modern Planter
- 1-1/4 in. x 6 in. drill bit
- Pavers
- Mexican Beach Pebbles
- Protective gloves
- Safety Eyewear



Step 1: Drill a hole on the bottom of the planter using the 1-1/4 in drill bit.

TIP! Wear safety glasses when operating an electric tool.



Step 2: Position the planter and make sure it is level.



Step 3: Place pavers into the planter depending on the desired height of your water feature.



Step 4: Assemble the Container Fountain Kit with Light and place it on the pavers. Run the cord down the planter and out the hole in the back.



Step 5: Apply epoxy to fill the hole that the cord is running through. Ensure enough slack is in the cord so you can position the kit in the center of the planter. Wait at least 1.5 hours for the epoxy to harden. Do not move the cord during this time.



Step 6: Add pebbles and fill with water. Once the pump is fully submerged, plug it in and enjoy!