







No	Adet Qty.	Parça • Parts	No	Adet Qty.	Parça • Parts
A	1 x	 (Arka Çamur Sıyrıcı) (Rear Spray Guard)	C	6 x	 (M5 Somun) (M5 Nut)
B	2 x	 (Aparat) (Apparatus)	B	6 x	 (5x10 Pul Başlı Civata) (5x10 Washer Head Bolt)

Gerekli Aletler • Required Tools	
 (4 Alyan) • (#4 Allen)	 (8 Yarım Anahtar) • (#8 1/2 Key)

## Montaj Talimatları

- 1- Aşama 1'de gösterildiği gibi motosikletinizin maşasında bulunan civatayı sökün.
- 2- Ayağı 2. aşamada gösterilen konuma maşadan söktüğünüz civatayla sabitleyin.
- 3- Aşama 3'te gösterildiği gibi çamur sıyrıcıyı, civata deliklerinin ayaklardaki deliklere denk gelecek şekilde konumlandırın, 5x10 pul başlı civata ve M5 somun kullanarak sabitleyin.

## Mounting Instructions

- 1- Remove the bolt from the fork of your motorcycle as shown in step 1.
- 2- Position the apparatus in the place shown in step 2 and fix it with the original bolt.
- 3- Position the rear spray guard so that its holes match the holes on the apparatus as shown in step 3 and fix it using 5x10 washer head bolts and M5 nuts.

