



SHORT EBAY FOR 5.5" AND 7.5" KITS



In addition to the traditional ebay instructions the SHORT ebay is constructed a bit differently. Pictured above is the part layout.

1. With coupler standing on end, insert one ebay bulkhead all the way down so it's flush with the end. This will be the removable bulkhead. Insert 1 stiffy coupler. Insert the other bulkhead so it's flush with the stiffy. Tack top bulkhead into place. Allow to cure. Use thick epoxy so it does not leak down to stiffy!
2. Flip coupler over on other end. Remove bulkhead and stiffy.
3. Slather epoxy into coupler, push/rotate stiffy down so it meets the bulkhead. Allow to cure.
4. Flip coupler on other end. Slather epoxy inside the coupler Push/rotate other stiffy so it's flush with the bulkhead in the center.

The RECOVERY end of the ebay is meant for apogee deployment as many times the motor tube length doesn't allow for much recovery room.

Any questions please reach out to us at 920.892.0557 or email us at info@locprecision.com