



www.irmmoto.com

sales.irmfg@gmail.com

IRM Moto Sahara Pegs

Fits BMW R1200RT, R1200GS, R1200RS, R1200R

Parts List




- (x1) Left assembly
- (x1) Right assembly
- (1) 7/64" Allen wrench

Tool List

- 7/64" Allen wrench
- Threadlocker


IRM Moto Sahara Peg Installation Instructions



ID	Description
a	6-32 x 1-1/2" bolts
b	Retaining clip
c	Mount
d	Footrest

Installation Instructions


1. Remove the spark plug cover from the valve cover
 - Pull on the area where the spark plug wires traverse through the plastic, pull out and forward




2. Select the correct assembly for each side
 - R or L is engraved on the back of the mounts
3. Using a 7/64" Allen key, remove the (x4) 6-32 bolts holding the retaining clip onto the Sahara assembly
 - Take note of the orientation of retainer clip for assembly later

IRM Moto Sahara Peg Installation Instructions

- Place the Sahara Peg retaining clip into the valve cover from the back, then slide it forward until it hits the stop.
 - Notice the orientation of the retaining clip




- Place the Sahara Peg into the valve cover



IRM Moto Sahara Peg Installation Instructions

6. Using (x4) 6-32 bolts, attach the retaining clip to the Sahara Peg
 - Use threadlocker
 - Tighten bolts in a cross pattern to ensure proper peg fit
 - When bolts are tight there will still be space between the retaining clip and the mount, do not continue to tighten to try to eliminate this gap and strip the threads



7. Repeat for the other side
8. Retighten after the first ride

Care and Maintenance

1. Periodically check the tightness of the retaining clip bolts
2. Apply grease to the pivot and detent mechanism regularly