

## Floor Pan Installation Guide

The HushMat Ultra floor pan kit is designed to treat from the point that the firewall meets the floor pan, across the tunnel to the side rail of the passenger back to the side of the “waterfall” – the vertical section that rises from the floor pan to the edge of the rear seat.



Remove the seats, carpet and trim panel sections surrounding the firewall and tunnel on both driver and passenger side. Remove carpet pad and any loose foam pieces down to the floor pan surface. There no need to remove factory damping material unless it is delaminating or flaking. If it is delaminating or flaking just remove the loose pieces.



Start at one straight edge (side rail or base of the firewall) and work either side to side or front to back. About the sheet edges or overlap slightly using HushMat's Hush Pro Roller to press down on the material. A single layer of material provides outstanding sound and thermal insulation performance.

# HushMat®

EXPERTS IN AUTOMOTIVE ACOUSTICS & THERMAL MANAGEMENT

Remove one sheet from the box and before you peel back the release paper place it onto the surface you plan to install it. Make impressions in the foil of the sheet marking any cut-outs you will have to make. Make your cut outs while the release paper is still intact. Using a razor knife cut out all necessary areas. Then peel back the release paper at one side and place that side directly on the surface. Apply uniform hand pressure to the sheet and peel back the release paper from the underside applying pressure as you progress across the sheet. If any air-bubbles form under the sheet poke the center of the air bubble with your knife and press the sheet down to the surface allowing entrapped air to escape.

Repeat the above steps until the floor pan is covered. HushMat Ultra is proven to remove a minimum of 40% of the thermal transfer penetrating the floor pan and tunnel. If the pre-HushMat treatment surface temperature is greater than 180° F, we recommend you install Silencer Megabond ½ inch insulating foam directly on top of the Ultra. Follow the same process of planning the Silencer Megabond install.



HushMat is manufactured in the United States of America and has been for over three decades. Easy to install and performs for the life of your vehicle. Tag photos or video of your install with #HushMatUSA

*The above provides an installation guide for your vehicle. It is not intended to reflect the exact dimensions of your Make, Model and Year vehicle.*

HushMat  
15032 West 117th Street  
Olathe, KS 66062 | 913.599.2600

[hushmat.com](http://hushmat.com)

**#1**  
Rated

Sound Deadening  
& Thermal Insulation  
Products