



Eurowise 996 Porsche Bumper Light Mounts

Product includes.

- 2x Light brackets
- 4x M8x35 hex bolts
- 4x M8 washers
- 4x Flanged nuts

You will need a 21/64 drill bit. a larger one will work as well but we used 21/64 for our install.





First remove the front bumper to access the crash bar.

From the center of the reinforcement bar mark the center and measure out 7 inches from each side. now mark the lines.





Now measuring the center of the light mount you will line up with your reinforcement marks and mark two holes for drilling.

Now use supplied hardware to install brackets. Install the bracket completely and move onto trimming the bumper next.



Next you need to trim the bumper opening for the bracket. It's roughly 2.25 inch opening at the bottom and the top.

Cut the opening using a Dremel or mini saw. Now you can install the bumper back on.



***IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT
PLEASE CONTACT US!***