



Eurowise Front lower FOX steering stabilizer

Disclaimer: This installation guide is provided for informational purposes only. We are not responsible for any damage or injuries resulting from improper installation or use of this product. It is essential to follow all safety guidelines and maintain safe installation habits. We strongly recommend that you consult with or hire a professional installer to ensure proper installation. Use this guide at your own risk.

The following is instructions for the product

<https://shop.eurowise.com/products/w463fss>

1. Remove three lower left differential bolts. 13mm bolts. Seen below.





2. Bolt Supplied bracket on using the supplied (3) 13mm bolts.



3. Bolt on the shock side with the shock body directly under the steering rod. the bolts will screw in from the top downwards.



4. If you measure from the end of the locking nut at the pitman arm. You will be approx. 12.5 inches from end to end. this will cause no binding issues turning lock to lock from left to right.





5. Install the large bolt on the differential side next. You can torque this bolt completely at this time.

***IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT
PLEASE CONTACT US!***