



## ***Porsche Macan Slider installation***

-6x Small L bolts (cut 2 1" off)

-2x M12 nutserts large

-2x M12x30 Hex bolts

-2x M12 washers

- Remove both left and right underbody plastic covers. You will not reuse these.
- Installation hardware pack you will see Special L bolts along with paper circles. You will install the paper over the stud to keep the L bolt from falling into the frame.







Insert the L bolt into the pockets of the front and rear.



Front seen with the large nutsert installed. Also, L-bolt installed on the right side.





Nutsert tool not included but can be purchased on our website to make installation simple. Otherwise, it is a M12 nutsert tool.







Install serrated nuts on the L bolts with the slider in place.





Once L-Bolts are inserted and the nutsert is installed. You can install the sliders. The nutsert will receive the 1 M12 bolt and other spots will get the Flanged serrated nuts.





**IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT  
PLEASE CONTACT US!**

**440 SPRINGBROOK ROAD. CHARLOTTE, NC 28217 | 704-559-8100  
INFO@EUROWISE.COM | WWW.EUROWISE.COM | SHOP.EUROWISE.COM**