

tradeshowplus

Graphics With Holes: Sandwich graphic in between Mightee Mounts (1A) and screw together with wingnuts and carriage bolts (1B).

Graphics Without Holes: Screw Mightee Mounts (2A) together with wingnuts and carriage bolts and rest graphic on top of screws (2B).

For MM12 Only: Plug screw hole

Base holds any rigid substrate up to 1" thick (as long as the substrate can hold its own weight).

For MM12 model only: holds any rigid substrate up to 3/16" thick and uses screws instead of wingnuts/bolts, but assembly remains the same.

