

Mounting Brackets Specifications

* Allowable error tolerance exists for manual measurement.

Brackets Type	Brackets Wireframes	Specification
Standard Bracket (Roller Blinds) Deco Bar Cassette		(A)=2 ³ / ₈ " (A)=6cm (B)=1 ¹ / ₈ " (B)=2.8cm (C)=1 ¹ / ₈ " (C)=2.8cm (D)=1 ⁵ / ₈ " (D)=4.1cm
Bracket (Honeycomb Blinds)		(A)=1 ⁵ / ₈ " (A)=4.1cm (B)=1 ¹ / ₄ " (B)=3.2cm (C)=1 ¹ / ₈ " (C)=2.8cm (D)=1 ¹ / ₈ " (D)=2.8cm
Bracket (Outdoor Blinds)		(A)=2 ¹ / ₈ " (A)=5.3cm (B)=3 ³ / ₈ " (B)=1cm (C)=1 ⁷ / ₈ " (C)=4.7cm (D)=3 ³ / ₄ " (D)=1.9cm
Bracket (Dual Roller Blinds)		(A)=3 ⁷ / ₈ " (A)=9.9cm (B)=2 ¹ / ₄ " (B)=5.7cm (C)=5 ³ / ₄ " (C)=14.6cm (D)=1 ⁵ / ₈ " (D)=4.1cm (E)=1 ⁵ / ₈ " (E)=4.1cm
Bracket (Woven woods)		(A)=2 ¹ / ₂ " (A)=6.3cm (B)=1 ³ / ₄ " (B)=4.4cm (C)=1" (C)=2.5cm (D)=1 ¹ / ₈ " (D)=2.8cm
Extension Bracket	<ul style="list-style-type: none"> • Windows with handles, and you want to choose blinds rollback rather than rollfront side. • Special shaped window frame. (eg: round shape window, side mounted.) 	(A)=3 ¹ / ₈ " (A)=7.9cm (B)=1 ³ / ₄ " (B)=4.5cm (C)=1 ¹ / ₄ " (C)=3.2cm
Bracket (Square Cassette)		(A)=2 ¹ / ₂ " (A)=6.2cm (B)=1 ¹ / ₄ " (B)=3.1cm (C)=1 ¹ / ₄ " (C)=3.1cm (D)=1 ³ / ₈ " (D)=3.5cm
Standard Screw		(A)=1" (A)=2.5cm (B)=1 ¹ / ₄ " (B)=0.5cm
Screw (Remote)		(A)=5 ⁵ / ₈ " (A)=1.5cm