

HANGING INSTRUCTIONS

NON-WOVEN FIBRE

Luxurious, textile-like touch. Handcrafted look and feel with an ultra matte finish.

Easy to install and strippable.

PLEASE READ THROUGH BEFORE HANGING. Inspect your wallcovering for defects prior to installation. No claims will be honored after merchandise has been cut or hung. No labor claims will be honored for any reason.

NOTE: The highest quality of workmanship is employed in the production of the wallcovering. Careful inspection is made before shipment, however, final inspection and approval are the ultimate responsibilities of the customer. Correct design, color and quantity should be verified before the wallcovering is cut or hung.

PREP:

Remove all old wallpaper and repair damaged areas. All walls must be smooth, clean, and free of mildew and grease stains. If necessary, apply a stain killing primer. Be sure newly plastered walls have been washed with a zinc sulfate solution. New, unpainted surfaces should be sealed with an oil based primer. Follow up with a high quality wallcovering primer sold in your local paint & wallpaper stores. **DO NOT USE GLUE SIZE.**

PRO TIP: On all surfaces that are to be papered, we recommend using a universal, pigmented wallcovering primer/sealer such as Shields. The pigment should be the same color as the background color of your wallpaper.

INSTALLATION:

Trimming - Refer to join marks on paper edge for pattern match (half drop/straight match). Use trim marks provided to trim selvage from edges of paper on a table.

Setup - Create a plumb line using either a laser or by drawing with a straight edge and level. *Use only a lead pencil for marking walls and back of wallcovering. Do not use ballpoint or marking pen as they will bleed through the surface.* This will be your guide for positioning the first panel.

Pasting - This stain-resistant strippable wallcovering can be hung BEST with a clear premixed adhesive. Apply paste to the wall. Cut in the edges with a brush and roll the main area. Apply a coat of adhesive over the area of the drop plus 2" into the next drop. Hang the trimmed piece within 2 minutes, do not let the wall paste dry. *Time is subjective to heat or humidity at job site. Different climates will affect drying speed of paste.*

Hanging - Position the first panel along the plumb line. Use a smoothing brush to remove all air pockets, wrinkles and excess paste by brushing the wallcovering from the center to the edges. A seam roller can be used to lightly roll edges of paper being careful not to push paste out. Repeat the procedure with the second panel, sliding it into position with its edge butted up against the edge of the preceding panel. Be sure to

match up the design. Do not overlap the wallcovering. Wash any glue residue from surrounding wood trim/molding immediately upon hanging each panel.

USING A CLEAN, DAMP SPONGE, GENTLY WASH ADHESIVE COMPLETELY FROM THE SURFACE OF THE WALLCOVERING IMMEDIATELY AFTER EACH STRIP IS HUNG. ANY ADHESIVE LEFT ON THE WALLCOVERING CAN, AT A LATER DATE, ATTACK THE SURFACE PRINTED INKS AND CAUSE THEM TO FLAKE.

**** This wallpaper is provided on a continuous bolt ****

For best results, please CUT AND HANG PANELS IN THE ORDER THAT THEY COME OFF THE BOLT. This provides the most consistent color from panel to panel. Work in one direction around the room, with the first and last panels from the bolt meeting in a corner, doorway, etc. - rather than on a flat wall.