



## Modification Guide for CZ 1012 G2 for LPGWorks Shell Catcher

Due to the location of the charge handle on the CZ 1012 G2, there isn't enough clearance between it and the required height of the shell catcher as shown below.



The charge handle will need to be modified as follows.

Remove approximately **1/64 (.0196) of an inch / .5mm** of material in the area marked on the charge handle in black below.

