



Installation Guide for Winchester SX 4

1. Use included alcohol wipes and clean the side of the receiver and wait till dry.
2. There is a thin stainless steel plate that is attached to the back inside of the shell catcher.
3. Remove the 3M adhesive back from the stainless steel plate and ensure it fit inside the recess of the shell catcher.
4. Line up the notch on the bottom of the shell catcher with the hole on the edge of the loading port.
5. Once aligned, push the shell catcher up and onto the ejection port. This will ensure the stainless steel plate adheres onto the correct location.
6. Once installed, the shell catcher can be removed. Press down on the stainless steel plate to ensure that it has proper adhesion on the receiver.
7. The stainless steel plate will remain on the receiver and allow the shell catcher something to stick to.