



JERRY CAN/ACCESSORY TRAY
INSTALLATION GUIDE

With the Accessory Tray or Jerry Can Basket, the plain and hitch risers install to swingarm using the 1/2" bolts provided in your hardware kit:

TIP: hitch should face center of the vehicle



Next, use the 3/8" bolts to secure the crossbar in the middle:



Finally, secure the basket to the risers using the 1/4-20 counter-sink bolts:



If Jerry Can Basket was purchased, it is assembled using the separate hardware kit. This kit contains twelve 5/16" bolts required for the final step of the Triple Jerry Can Basket installation process.

Use five of the 5/16" bolts on each side for of the tray's side panels. Use the remaining two 5/16" bolts to secure the back/bottom of the tray's back-plate:

