



**OVERLAND PRO & LADDER**  
INSTALL GUIDE

## 1. OVERLAND PANEL/LADDER ASSEMBLY

**1.1** Once the swing arm is installed proceed with the attachment of the two lower risers. Each side mounts to the swing arm at three attachment points, however, if you purchased the Overland Pro Swingout— Only start with the two attachment points specified below, the third attachment point will be used later to integrate the lower tray.



**1.2** Next install the lower panel onto the lower risers using at least 4 sets of hardware at each corner. The correct panel will properly line up with the various cutouts and notches as highlighted below:



**1.3** Next install the upper uprights. These are left and right specific and attach to the lower risers with two sets of hardware on each side. See highlights below for orientation of the angle cuts. Once uprights are bolted proceed with the installation of the upper panel using 4 sets of hardware at each corner. The cutouts on the panel will align with the risers.



**1.4** Attach the upper and lower panel together using three sets of hardware





(Ladder Rungs install using the provided bolts as shown)