

APPLICATIONS 1992-1995 Honda Civic (EG) / 1994-2001 Acura Integra (DC2) 1996-2000 Honda Civic (EK)*

*Made specifically for the EK chassis but can fit these other vehicle applications below. If your car has a dual stage airbag you may need two resistors instead of one.

2002-2006 Acura RSX (DC5) 2004-2008 Acura TSX - (Horn not compatible) 1994-1997 Honda Accord 1998-2002 Honda Accord 2001-2005 Honda Civic (all) 2007-2009 Honda Fit 1997-2001 Honda Prelude 2000-2009 Honda S2000

INSTALLATION GUIDE

PN: CH-SWH-EG, CH-SWHB-EG CH-SWH-EK*, CH-SWHB-EK* Circuit Hero Steering Wheel Hub Adapter

Included

(1) Billet Hub(1) SRS Warning Light Resistor(6) Countersunk Allen Bolts

Fits 6-Hole Pattern Steering Wheels

6 x 70mm (Circuit Hero, Momo, OMP, Sparco 6 x 74mm (Nardi, Personal)

PRODUCT DISCLAIMER

Some products may not be legal for use on public highways. It is the purchaser's responsibility to check and comply with all local, state and federal laws before installing components and operating vehicle. The installation and the use of some Circuit Hero performance products may also affect or void a vehicle's manufacturer warranty and insurance policy. Circuit Hero assumes no responsibility for any damage or injury to persons or property resulting in improper installations or misuse of any product and will not be responsible for any claims of loss of profit, labor and delay, indirect, incidental or consequential damages that might be claimed as a result of failure of any part. Circuit Hero reserves the right, without notice, to make changes in materials, specifications, product design, part numbers, packaging and labeling without incurring any obligation to the buyer for the previously purchased merchandise.

1. Make sure the front wheels are pointed straight ahead.

2. Disconnect the vehicle battery.

3. Remove existing steering wheel (refer to your

Repair Manual).

4. Position hub on splined/keyed steering shaft

column ensuring that the top of the hub orientation

is correct. Secure using OE bolts.

5. Thread wiring through the horn wire hole, and

slide the hub adapter down the shaft.

- 6. Connect SRS Warning Light Resistor.
- 7. Attach horn trim ring and install steering wheel.
- 8. Connect horn wiring and attach horn.
- 9. Reconnect the vehicle battery and test horn.





(f) 🙆 🕑