

2016-2023 CARRIER BEARING INSTALLATION INSTRUCTIONS

TOOLS NEEDED:
RAMPS OR JACK STANDS
15MM SOCKET
6" EXTENSION

NOTE: PRODUCT FITS 2016-2022 PILOT AND 2016-2023
PASSPORT AND RIDGELINE.

IMAGE 1



1) YOU'RE GOING TO WANT TO GET THE VEHICLE UP OFF
THE GROUND TO MAKE YOUR LIFE EASIER.

2) LOCATE THE CARRIER BEARING(S) UNDERNEATH THE
VEHICLE. THERE ARE TWO ON THE RIDGELINE AND ONE ON
THE PILOT AND PASSPORT.

3) BEGIN BY REMOVING THE TWO BOLTS HOLDING THE CARRIER BEARING. BE AWARE
THAT THE DRIVESHAFT WILL FALL WHEN THE BOLTS ARE REMOVED.

4) PLACE THE CARRIER BEARING SKID BETWEEN THE TRUCK AND THE CARRIER
BEARING AS SHOWN BELOW, AND REINSTALL FACTORY HARDWARE.

2016-2023 CARRIER BEARING INSTALLATION INSTRUCTIONS



***BE SURE AND MAKE USE OF THIS SERVICE HOLE. IT WILL MAKE THE
INSTALL MUCH SIMPLER.**

**6) PLACE THE SOCKET ON THE BOLT AND THEN RUN AN EXTENSION
THRU THE SERVICE HOLE (ABOVE IN RED) IN THE SKID PLATE TO
REINSTALL BOLTS. TIGHTEN TO 41 FT-LBS.**

YOU'RE DONE! PROTECTED FOR YOUR NEXT ADVENTURE!

***PLATE USED IN PHOTOS MAY DIFFER FROM YOUR PLATE. WE ARE ALWAYS WORKING TO IMPROVE OUR
PRODUCTS AND THE NEWER VERSIONS MAY DIFFER SLIGHTLY FROM IMAGES.**