

## Mirror bracket install:

### Tools:

- Plastic Pry bar
- 10mm socket or wrench
- A way to trim the Plastic (Dremel, die grinder)

Start by removing the plastic trim piece in front of the mirror. This can be done with a plastic pry tool or in some cases by hand. The door needs to be open to remove the trim piece. It has three plastic feet holding it in place.



Once the plastic trim piece has been removed. Remove the fender bolt just below the removed trim piece. This bolt can be seen when the door is open. Folding the mirror in will give you more room to work.



Next install the bracket with the provided hardware. Be sure the bracket is far enough forward that it doesn't interfere with the door's operation. Tighten to 10 ft-lbs.



## Modifying the Plastic trim

The easiest way to do this is to mock up the trim on top of the mirror bracket. Mark the removed plastic trim and cut according.



Remove the plastic in small amounts so as to not make the opening too large. This will keep this modification looking clean. The bottom mounting leg of the trim piece needs to be shaved down too. If you have removed enough plastic from the outer edge but the trim piece isn't fitting this is likely the problem. Once the trimming is complete you can finish up the install. We recommend running wires or antenna cables at this point in time.

Once you have everything wired up snap the trim piece back into place and repeat the process on the other side of the vehicle.