

INSTALLATION INSTRUCTIONS - INS035

1979 - 2004 MUSTANG

PERFORMANCE REAR UPPER CONTROL ARMS

Part # 2522



SPECIAL TOOLS REQUIRED: Jack-stands, floor-jack.



INSTALL TIME: Approximately 3 hours.



DIFFICULTY: Average.



IMPORTANT! Use extreme caution when working under vehicles.



 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019



FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 1

Carefully place the rear of vehicle on jack stands located at the frame – not the rear axle.

CAUTION! Use extreme caution when working under vehicle.

STEP 2

Using a hydraulic floor jack, raise the rear axle housing under the center section until the axle reaches approximate ride height. Place jack stands under the axle for safety.

STEP 3

Working on one side at a time, remove upper control arm by removing two bolts securing it to the chassis and rear-end housing. Apply a liberal coating of general purpose grease on the new control arm bushings. With grease Zerk facing the ground reinstall and tighten control arm completely, using a drop of Loc-Tite™ on each mounting bolt.

STEP 4

Follow the same procedure for the other side.

STEP 5

You may now lube both grease fittings and reinstall dust caps.

STEP 6

Drive the car for approximately 5-10 miles, recheck all nuts and bolts for proper torque specs.

 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019