


## **INSTALLATION INSTRUCTIONS - INS189**

# HEADER

Part # 4052 and 40520 // 1993-1999 Jeep Wrangler 4.0L and Jeep/Grand/Cherokee 4.0L 2WD & 4WD







IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.





## STEP 1

Disconnect the negative battery terminal.

# STEP 2



Loosen the clamp at the throttle body by pulling the locking tab up.

### STEP 4



From underneath the vehicle remove the 3 nuts that secure the stock air box assembly.

# STEP 3



Remove the clips holding the top half of the stock air box assembly together to the bottom half, and also remove both-vent hoses going to the air box.

## STEP 5



While still underneath the vehicle, remove the hardware from the collector to the head pipe.

■MADE IN U.S.A.■

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.





## STEP 6



REMOVAL OF THE STEERING PUMP
Remove the long adjusting bolt from underneath the steering pump.

### STEP 8



Remove the top bolt on the black bracket above the pump and the nut on the bottom of the steering pump.

## STEP 7



Remove the 2 mounting bolts on the back of the steering pump.

## STEP 9



After removing the belt and un-mounting the steering pump, move it off to the side to aid in Header installation.

MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.





## STEP 10



Remove the 3 bolts holding the steering pump bracket to the intake manifold.

### STEP 12



Unplug all the electrical connections going to the throttle body. Unbolt and remove the throttle body.

# STEP 11



REMOVAL OF THE THROTTLE BODY
Unclip the cable attachments from the throttle body linkage.

## STEP 13



REMOVAL OF THE INTAKE MANIFOLD Unbolt the bracket holding the throttle body cables and move to the side.

MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.





### STEP 14



Disconnect all the fuel injector connections (6 total) and any other electrical connections for the intake manifold.

### STEP 16



Remove all air lines (6 total) going to the intake manifold.

# STEP 15



Be sure there is no pressure in the fuel system and disconnect the 2 fuel lines going to the fuel rails by squeezing the tabs and pulling back on the lines.

# STEP 17



Remove all the bolts holding the intake manifold to the cylinder head.

■MADE IN U.S.A.■


IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.





### STEP 17 (CONT.)



Remove all the bolts holding the intake manifold to the cylinder head.

### STEP 18



REMOVAL OF THE STOCK EXHAUST MANIFOLD

Remove all the hardware and remove the stock exhaust manifold from the vehicle.

### STEP 19



INSTALLING THE BBK HEADER

Place the BBK Header into position and tighten the header down using the stock hardware.

#### STEP 20

#### RE-INSTALL THE INTAKE MANIFOLD

Re-install the intake manifold by repeating steps 13-17

## STEP 21

Tighten the intake manifold by starting from the middle bolts and going outwards.

# STEP 22

Re-install the throttle body and steering pump. When tightening the belt adjuster (long bolt on bottom of the steering pump) there should be no more than ¼ inch of total play in the belt.

MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.







### STEP 23



Re-install the Air Intake Assembly and tighten the header to the head pipe using the supplied hardware.

## STEP 24

Reconnect the negative battery terminal



INSTALLED ON THE VEHICLE







IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

