



Requirements:

2 People (recommended)
Carpenter's Hammer
Cordless Drill
Tape Measure
Rubber Mallet

View the assembly process





Parts List

Part#	<u>Description</u>	Quantity
BASE		
805901 805902 805903 805904 CT3672HARDWARE CT3672MANUAL	Long Front Bar Wall Short Side Bar Wall - Left Short Side Bar Wall - Right Assembled Bar Top with 2 Holes Southern Fantasy Hardware Package Southern Fantasy Tiki Bar Owners Manual	1 1 1 1 1 1
	<u>Options</u>	
BCT3672C	3 Door Cabinet	
805913 805914	Front Cabinet Panel with 3 Pre-hung Doors 11"x47-1/4" Cabinet Top & Base	<u>1</u> 2
BCT3672P	Palm Thatch Roof	
805905 805906 805907 805908 805909 805910 805911	Log T Post for Roof Assembled Roof Rafters Log Roof Bottom Side Plate with 4 Holes 70" Roof Peak Boards (angled cut side) 70" Roof Bottom Boards (straight cut side) 70" Roof Boards (Toungue & Groove) 72" Palm Thatch Section	2 4 2 2 2 6 2
BCT3672S	Synthetic Thatch Roof	
805905 805906 805907 805908 805909 805910 805912	Log T Post for Roof Assembled Roof Rafters Log Roof Bottom Side Plate with 4 Holes 70" Roof Peak Boards (angled cut side) 70" Roof Bottom Boards (straight cut side) 70" Roof Boards (Toungue & Groove) Synthetic Palm Thatch Sheet	2 4 2 2 2 6 12



<u>Index</u>

Parts List

Base Assembly

3 Door Cabinet Assembly (Optional)

Roof Assembly (Optional)

Palm Thatch Installation (Optional)

Synthetic Thatch Installation (Optional)

Care & Maintenance

Warranty



Base Assembly



Organize your pieces neatly on the ground.



Set up the left and right short side bar wall pieces as shown.



Slide the long front bar wall into place.



Holding the walls flush together, secure them together using the provided 2 ½" (64mm) screws from the inside of the long front wall into the short side walls.

Manufactured by:



Base Assembly



With a helper, place the bar top on top of the assembled frame.



Secure the long front wall to the bar top from underneath with 2 ½" (64mm) screws.

Be careful not to overtighten as the screws could go through the top of the bar.



Screw the bar top to the side walls using a 2 ½" (64mm) screw by screwing on an angle through the post holes into the wall.

Repeat on opposite side.

This completes the assembly of your Southern Fantasy Tiki Bar Base.



3 Door Cabinet Assembly




To assemble the cabinet in your Southern Fantasy Tiki Bar it is important to use the top and bottom shelves in the correct location.

To tell the difference between the top and bottom, determine the pre-drilled hole locations.

Bottom- Holes facing ends Fig.1



The top shelf will have the pre-drilled holes facing the edges only. Fig. 2



Place the bottom Shelf on a flat surface with the predrilled holes on the bottom.

With the doors opening outward and handles to the top, line up the cabinet so it is flush to the edge of the bottom shelf and secure with $2 \frac{1}{2}$ " (64mm) screws.



Ensure the top shelf is flush to the edge of the top of the cabinet and secure from underneath up into the top shelf with $2 \frac{1}{2}$ " (64mm) screws.

The pre drilled holes in the top shelf should be facing away from the cabinet and on the bottom.

Manufactured by:



3 Door Cabinet Assembly



Lay the tiki bar on its front.

(use a blanket to prevent it from getting damaged)

Gently place the completed cabinet inside the tiki bar. Note the orientation of the door handles should be to the top.



Make sure the bottom of the assembled cabinet is flush to the bottom of the tiki bar and secure with 2 ½" (64mm) screws in the pre-drilled holes.



Carefully stand the tiki bar back up.



Secure the top shelf to the front wall using 2 ½" (64mm) screws in the pre-drilled holes.

This completes the assembly of your Southern Fantasy Tiki Bar 3 door Cabinet!

Manufactured by:



Roof Assembly



Slide the log T posts into each of the holes in the bar top.

Finesse them into place until the posts hit the bottom of the side walls.



Lay out one of the log roof bottom side plates.

Insert an assembled roof rafter into each of the holes.



Insert the other log roof bottom side plate onto the other ends of the roof supports.

Tap tight with a rubber mallet if necessary.



Make sure the roof supports are straight and secure each joint with a 2 ½" (64mm) screw.

Manufactured by:



Roof Assembly



Locate the roof peak boards. (Angled cut side)

These will have a 45 degree cut on the top side.



With the roof peak boards centered and overhanging on each end of the assembled roof evenly, hold them flush together at the top of the roof and secure to each roof support with a 2" (51mm) screw.



Install the roof boards (tongue & groove) working your way down each side of the roof.

Screw 2 - 2" (51mm) screws into each board at each roof support.

You may need to tap the boards with a rubber mallet to ensure they are tight together before screwing.



Make sure the roof supports are straight and secure each joint with a 2 ½" (64mm) screw.

Manufactured by:



Roof Assembly



Locate the roof peak boards. (Angled cut side)

These will have a 45 degree cut on the top side.



With the roof peak boards centered and overhanging on each end of the assembled roof evenly, hold them flush together at the top of the roof and secure to each roof support with a 2" (51mm) screw.



Install the roof boards (tongue & groove) working your way down each side of the roof.

Screw 2 - 2" (51mm) screws into each board at each roof support.

You may need to tap the boards with a rubber mallet to ensure they are tight together before screwing.



Install the roof bottom boards (straight edge on bottom) on each side.

Manufactured by:



Southern Fantasy Tiki Bar Assembly Instructions Palm Thatch Roof



Unroll your one of the palm thatch sections and line it up at the top of one side of the roof.



Using a hammer, fasten the palm thatch to the roof using the provided staple clips.



These should be placed approximately every 8" and at least three rows per side.



Repeat on other side of roof.



Southern Fantasy Tiki Bar Assembly Instructions Palm Thatch Roof



With at least 2 people, lift the assembled roof onto the top of the bar posts.



Using a tape measure, ensure the overhang on each end of the roof sits even.



Once the roof is even on each end, pre-drill holes in each of the T posts lining the hole up with the roof bottom side plates.

Secure each corner of the T post to the roof bottom side plates using the provided 3 ½" (89mm) screws.



Secure the assembled bar to the T posts from the inside using a 2 ½" (64mm) screw.

Repeat on other end of bar.

This completes the assembly of your Southern Fantasy Tiki Bar Palm Thatch Roof!



Congratulations on the assembly of your new Southern Fantasy Tiki Bar!



Care & Maintenance

* The Southern Fantasy Tiki Bar is coated with a water based outdoor clear coat.

To maintain this look, it may be required to re-apply a finish depending on the weathering.

The natural palm thatch roofing material should be removed and stored indoors in the winter or when not in use for an extended period of time.

In harsher climates, simply covering the palm thatch roof with a tarp for the winter is not advised as it could cause the natural thatch to mold.

The synthetic thatch can be left outside year-round.



Warranty

Canadian Timber Collection Saunas warrants our saunas against defects in materials and workmanship under normal/residential use for a period of five (3) years, as applicable, from the date of receipt of the product by the original end-user consumer. This warranty does not apply to normal wear and tear and/or natural weather conditions. This warranty does not cover regular required maintenance of the sauna, (eg. Tightening bands on the barrels, cleaning or staining the sauna) refer to your sauna assembly manual for maintenance guidelines. This warranty does not cover misuse or negligence and the manufacturer and associated retailers are not liable for any injury or damage caused by the product. This warranty is a parts only warranty and any service or labor costs would not be considered as part of the 3 year warranty.

Purchaser Name: _	Date:
Purchased From: _	-

