



#### Requirements:

2 People (recommended)
Staple Gun
Cordless Drill (we supply the bit)
Tape Measure
Rubber Mallet
Utility Knife

View the assembly process





#### **Parts List**

Part #	Description	Quantity
BASE		
-		
<u>805920</u>	Long Front Bar Wall	<u>1</u>
<u>805921</u>	Short Side Bar Wall - Left	<u>1</u>
805922	Short Side Bar Wall - Right	<u>1</u>
<u>805923</u>	Assembled Bar Top with 2 Holes	<u>1</u>
CT4896HARDWARE	Tropical Paradise Hardware Package	<u>1</u>
CT4896MANUAL	Tropical Paradise Tiki Bar Owners Manual	<u>1</u>
	Options	
BCT4896C	2 Door Cabinet & Fridge Opening	
<u>805941</u>	Front Cabinet Panel with 2 Pre-hung Doors	1
<u>805942</u>	22"x28" Bar Top	<u>1</u>
<u>805943</u>	<u>16-1/2" x 36-1/4" Bar Top</u>	<u>1</u>
805944	63-1/4" Wide Assembled Cabinet Base	<u>1</u>
<u>805945</u>	21"x35-1/2" Assemble Fridge Cabinet Sides	2



#### Parts List (Optional Roof)

Part#	Description	Quantity
BCT4896P	Palm Thatch Roof	
805924	Log T Post for Roof	2
805925	84" Log Bottom Plate with Mitred Ends	<u>2</u>
805926	46" Log Bottom Plate with Mitred Ends	<u>2</u>
805927	38" Log Corner Rafter with 1 Mitred End	<u>4</u>
805928	28" Rafters with 1 Mitred End	<u>8</u>
805929	Assembled Roof Peak Box	<u>4</u> <u>8</u> 1
805930	90" 1x6 T&G with Straight Cut Bottom	<u>2</u>
805931	82-11/16" T&G Roof Board	<u>2</u>
805932	72-3/4" T&G Roof Board	2
805933	62-15/16" T&G Roof Board	<u>2</u>
805934	53-1/8" T&G Roof Board	<u>2</u>
<u>805935</u>	42-1/2" T&G Roof Board	<u>2</u>
<u>805936</u>	52-1/4" 1x6 T&G with Straight Cut Bottom	2 2 2 2
805937	44-9/16" T&G Roof Board	<u>2</u>
<u>805938</u>	35-5/16" T&G Roof Board	<u>2</u>
805939	26-1/16" T&G Roof Board	<u>2</u> 2
805940	16-3/4" T&G Roof Board	
805946	Palm Thatch Roll	1
BCT4896S	Synthetic Thatch Roof	
<u> </u>	Log T Post for Roof	<u>2</u>
805925	84" Log Bottom Plate with Mitred Ends	
805926	46" Log Bottom Plate with Mitred Ends	<u>2</u> 2
805927	38" Log Corner Rafter with 1 Mitred End	<u>=</u> <u>4</u>
805928	28" Rafters with 1 Mitred End	<u></u> <u>8</u>
805929	Assembled Roof Peak Box	<u>1</u>
805930	90" 1x6 T&G with Straight Cut Bottom	<u>2</u>
805931	82-11/16" T&G Roof Board	<u>2</u>
805932	72-3/4" T&G Roof Board	<u></u>
805933	62-15/16" T&G Roof Board	<u>2</u>
805934	53-1/8" T&G Roof Board	<u>2</u>
805935	42-1/2" T&G Roof Board	2
805936	52-1/4" 1x6 T&G with Straight Cut Bottom	<u>2</u>
805937	44-9/16" T&G Roof Board	2 <u>2</u> 2 2 2
805938	35-5/16" T&G Roof Board	<u>2</u>
805939	26-1/16" T&G Roof Board	<u>2</u>
805940	16-3/4" T&G Roof Board	<u>2</u>
805912	Synthetic Palm Thatch Sheet	<u>75</u>

#### <u>Index</u>

#### **Parts List**

**Base Assembly** 

2 Door Cabinet & Fridge Opening (Optional)

**Roof Assembly (Optional)** 

Palm Thatch Installation (Optional)

**Synthetic Thatch Installation (Optional)** 

**Care & Maintenance** 

**Warranty** 



**Base Assembly** 



Organize your pieces neatly on the ground.



Set up the long front bar wall where the Tropical Paradise tiki bar will be placed.



Slide one of the short side bar wall pieces flush into the front wall.



Holding the walls flush together, secure them using the provided  $2 \frac{1}{2}$ " (64mm) screws from the inside of the front wall into the side wall.

Manufactured by:



**Base Assembly** 



Repeat this process for the other side wall piece.



Place the bar top onto the assembled bottom base.

The bar top should "slip" over the assembled walls.



If the roof option is chosen, secure the bar top to the base through the post holes.

If the roof option is not selected, proceed to the next step.



Secure the tiki bar base to the bar top using the provided  $2 \frac{1}{2}$ " (64mm) screws from the inside of the front wall up into the bar top.

Be careful not to overtighten as screws will go through top of bar.

Manufactured by:



2 Door Cabinet Assembly



If no bar cabinet was chosen, skip the next 3 steps

Place the bar cabinet inside the base of the tiki bar.



Slide the bar cabinet tight to the front wall of the tiki bar.



Secure the frame on the inside of the bar cabinet to the tiki bar base using 2 ½" (64mm) screws.



Repeat the process by fastening inside the mini fridge compartment to the tiki bar base using 2  $\frac{1}{2}$ " (64mm) screws.

Manufactured by:



#### **Roof Assembly**



Slide the log T posts into each of the holes in the bar top.

Finesse them into place until the posts hit the bottom of the side walls.



Lay the roof frame on a clean flat surface.



Organize the roof support pieces.

There will be 4 – log corner rafter with 1 mitred end and 8 – short rafters with 1 mitred end.

The longer 4 are for the corners and the shorter ones go in between.



To make installation easier, pre place 3" (76mm) screws into the ends of the roof supports.

Manufactured by:



**Roof Assembly** 



Locate the assembled roof peak box.



With assistance from a helper, hold the corner roof support flush to the corner of the roof peak box. Secure the post to the assembly with 3" (76mm) screws. (2 screws per corner)



Repeat for the remaining 3 corners.



Center the roof peak box assembly on top of the roof frame.

Manufactured by:



**Roof Assembly** 



Screw the corners of the corner rafters to the roof frame using 3" (76mm) screws.

Ensure that the supports are centered on the corners.



Position one of the shorter rafters flush to the side and top of the side of the roof peak box and secure with 3" (76mm) screws.




Install 3 rafters for each side. 1 at either end and one centered between them.

Repeat for the other side.



Center 1 roof rafter on the end and secure as in the previous step.

Repeat for the other end.





**Roof Assembly** 



Screw the bottoms of the rafters to the roof frame using 3" (76mm) screws.



Gather up and organize your roof boards.

The short ones are for the ends and the longer ones are for the sides.



The roof boards are tongue and groove.

The boards with a straight cut on the groove side are for the bottom of the roof.



Starting on one of the sides, insert the shortest board up tight to the roof cap.

Manufactured by:



**Roof Assembly** 



Secure the roof boards into the roof rafters with the provided 2" (51mm) screws.



Continue adding the roof boards working around the roof assembly.

Use a rubber mallet to tap boards tight together.



Install the bottom roof boards in the same manner.

Manufactured by:



**Synthetic Thatch Installation** 



Gather up your synthetic palm thatch pieces.



Place the thatch onto the roof with the synthetic palm leaves hanging over the bottom as in picture.



Secure with staples

Please note you are going to want to use a lot of staples to hold thatch pieces to the roof.



Add the next piece of thatch overlapping the last piece by a couple inches.

(To keep the thatch level you can use the roof board as a guide for a straight line)

Manufactured by:



**Synthetic Thatch Installation** 



When you get to the end of the roof, cut off the excess thatch with a utility knife.



Use the cut off piece to start the first row on the short side. Cut the excess off the corner in the same manner.



Continue to add the synthetic thatch in this manner around the roof.



Cut some thatch into "thirds"
These will be used in the corners.

Manufactured by:



**Synthetic Thatch Installation** 



Take the cut corner pieces and fasten them to the corners with staples.

This will cover up the corners of the thatch underneath.



Fasten a row of thatch, then the cut corner pieces. Continue this method until you get to the top.



When you reach the top, overlap the 2 sides as shown.



Cut approximately 3-4" of the top of a few pieces of thatch.

Manufactured by:



**Synthetic Thatch Installation** 



Use these cut pieces to cover the thatch at the top.



Attach 2 more corner pieces at each end of the roof.



Use cut corner pieces to make a ridge cap cover coming in from each end until they meet in the middle.



Now cut some thatch pieces just past the leaf ends as in picture.

Manufactured by:



**Synthetic Thatch Installation** 



Overlap the 2 cut pieces back to back then secure into place with staples.

Secure any loose thatch you may find with staples



With a helper, place the roof up onto the bar posts.

Center the roof ensuring it is overhanging the same front and back and side to side.



Secure the bar posts to the assembled roof using the supplied lag screws.

Repeat on all 4 corners.



Secure the bar posts from the inside of the base using the provided 3" (76mm) wood screws.

Repeat on other side





# Congratulations on the assembly of your new Tropical Paradise Tiki Bar!



#### Care & Maintenance

\* The Tropical Paradise Tiki Bar is coated with a water based outdoor clear coat.

To maintain this look, it may be required to re-apply a finish depending on the weathering.

The natural palm thatch roofing material should be removed and stored indoors in the winter or when not in use for an extended period of time.

In harsher climates, simply covering the palm thatch roof with a tarp for the winter is not advised as it could cause the natural thatch to mold.

The synthetic thatch can be left outside year-round.

Manufactured by:



#### **Warranty**

Canadian Timber Collection Saunas warrants our saunas against defects in materials and workmanship under normal/residential use for a period of five (3) years, as applicable, from the date of receipt of the product by the original end-user consumer. This warranty does not apply to normal wear and tear and/or natural weather conditions. This warranty does not cover regular required maintenance of the sauna, (eg. Tightening bands on the barrels, cleaning or staining the sauna) refer to your sauna assembly manual for maintenance guidelines. This warranty does not cover misuse or negligence and the manufacturer and associated retailers are not liable for any injury or damage caused by the product. This warranty is a parts only warranty and any service or labor costs would not be considered as part of the 3 year warranty.

Purchaser Name: _	 Date:
Purchased From: _	

Manufactured by:

