

Either use contact adhesive, fast curing liquid nails or Soudal floor and wall adhesive:

- Ensure the surface area is completely clean before applying any adhesive
- Lay flat the bendy profile panels and get the material as flat as possible

Contact adhesive

- Make sure surface area is completely clean before applying any adhesive
- Lay the material flat and get the material as flat as possible
- Spray, Brush or Roll both area with a 50% overlay
- Wait 5-10 minutes until both surfaces are dry and slightly tacky
- Apply the material to the working surface pressing along make sure a good bond
- Recommended to use a laminate pressure roller for good bond
- If needed trim excess with a razor blade

Liquid nail adhesive

- Make sure surface area is completely clean before applying any adhesive
- Lay the material flat and get the material as flat as possible
- Best to use a polyurethane fast curing product
- Apply using a zig zag pattern
- Apply to the area with pressure so the glue spreads behind to create a good bond
- Recommended to use a laminate pressure roller for good bond
- Recommended to tack weak areas with nail gun or staple gun
- If needed trim excess with a razor blade
- Putty all areas needed
- Best to wait minimum 24hrs before painting

Soudal floor and wall

- Make sure surface area is completely clean before applying any adhesive
- Lay the material flat and get the material as flat as possible
- Apply with a B3 trowel or small tooth trowel in random patterns
- Apply adhesive to a clean working area
- Apply the material to the working surface with pressure recommended to use a laminate pressure roller for good bond
- Recommended to tack weak areas with nail gun or staple gun
- If needed trim excess with a razor blade
- Putty areas
- Best to wait minimum 24hrs before painting