

How to install a Bobcat 14 Pin harness the proper way. This method is not approved by Bobcat.



My new machine came in looking like this so I came up with my own way of installing the 14-pin connector in a professional manner. When I contacted said manufacturer with my findings, they told me that my boom warranty was voided. I told them that if their boom was that weak, then that would be the last machine I ever bought from them and it was. I am now 100% Kubota. For those of you that want it done right, here is how I did it.

<p>Locate an area just below there coupler mounting area.</p>	<p>Using a magdrill, mill a hole 1/8" larger than their connector that they use for their 14pin.</p>	<p>The hole dilled will look like this. You can now slide a fish inside and back the boom and attach the end of the wiring loom to it</p>
<p>You can use the tie down hole to help push the connector up through your drilled hole.</p>	<p>Here is what it looks like years later. Still fully functional and protected.</p>	