



## TIE DYE WAX MELT RECIPE



# CANDLE SHACK

## WHAT YOU WILL NEED

[1x Clamshell - 4 Cavity](#)

[5g Marine Fragrance Oil](#)

[45g RCX Melt Blend](#)

[1 pinch of Bekro Dye - 78/3297 - Turquoise](#)

[1 pinch of Ice Mica Powder](#)

[1 pinch of Iridescent Mica Powder](#)



# CANDLE SHACK

## THE STEP-BY-STEP PROCESS

<b>STEP 1</b> Melt your wax in a double boiler or microwave.	<b>STEP 7</b> Pour a dash of the dyed wax into the squares of the clamshell.
<b>STEP 2</b> Once fully melted, add the fragrance.	<b>STEP 8</b> Straight away, put another dash of undyed wax into the clamshell pouring very slowly. Do not fill past halfway up the height of the squares.
<b>STEP 3</b> Split the mixture into half into two containers.	<b>STEP 9</b> Give your clamshell a little shake, which will help the two waxes to slightly blend without mixing them fully.
<b>STEP 4</b> In one of the containers, add the dye and mix until fully incorporated. Leave the other container undyed.	<b>STEP 10</b> Wait a while until the poured wax starts to dry.
<b>STEP 5</b> Add the mist mica powder to the dyed wax and mix until fully incorporated.	<b>STEP 11</b> Repeat steps 7 to 10 until your clamshell is full.
<b>STEP 6</b> In the undyed wax, add the iridescent mica powder and mix until homogeneous.	<b>STEP 12</b> Leave your wax melt to cure for 48 hours before use.