



HEART STUDDED CANDLE RECIPE

CANDLE SHACK

WHAT YOU WILL NEED

1x 50ml Candle Glass Bowl - Externally Matt White
32.55g of Velvet Peony & Oud Fragrance Oil
432.45g of CS1 Wax
1x Pinch of Bekro Dye - 35/4151 - Rose
3x LX12 Wicks
3x 15mm Adhesive Wick Pads
3x 40x25mm Wick Cores
1x Wax Melt Mould - Lush Hearts

THE STEP-BY-STEP PROCESS - MAKING THE WAX MELT HEARTS

STEP 1 Melt 83.7g of CS1 wax in a double boiler and bring it up to 80°C.
STEP 2 Add a pinch of dye and mix well for about a minute.
STEP 3 Add 6.3g of Velvet Peony & Oud fragrance and mix well for about a minute.
STEP 4 Fill the mould with the mixture and leave it to dry completely for at least an hour.
STEP 5 Demould when dry.

THE STEP-BY-STEP PROCESS - MAKING THE CANDLE

STEP 6

Clean your glass of any debris.

STEP 7

Apply stickum to the bottom of LX12 wicks, stick it to the glass evenly spread and thread wick cores on them, making sure they are straight.

STEP 8

Melt 348.75g of CS1 wax and bring it up to 80°C.

STEP 9

Add 26.25g of Velvet Peony & Oud fragrance and mix well for about a minute.

STEP 10

Pour the mixture into the prepared glass.

STEP 11

Leave the candle to dry for about an hour until it dips.

STEP 12

Using a flasher or a heat gun melt the top of the candle until you achieve an even surface.

STEP 13

Place the hearts on top of the candle in your desired pattern and push them gently into the wax so the hearts will be secure.

STEP 14

Leave the candle to crystallize for 48 hours.

STEP 15

Trim the wick to 5mm and enjoy!