



# Daily Operating Procedures

- Morning Start-up**
- ✓ Add water to the drip pan - approximately half full.
  - ✓ Cover center shaft with aluminum foil  
(Batch units only)
  - ✓ Apply "KOTE" liberally to all metal surfaces. DO NOT APPLY TO GAS BURNERS, IGNITORS, LOGS, ELEMENTS OR CERAMICS.
  - ✓ Preheat rotisserie prior to loading with product. A 20 minute preheat is acceptable.
  - ✓ Load product
  - ✓ Start the cooking process
- During The Day**
- ✓ Monitor the cooking cycle
  - ✓ When unloading product, ensure that the glass windows are wiped down to minimize fat/grease adhesion on the glass
  - ✓ Monitor drip pan level - add water if necessary
- Cleaning**
- ✓ Make sure unit heat and lights are turned off and cool.
  - ✓ Empty drip pan into proper waste container
  - ✓ Refill drip pan with soapy water to use for cleaning inside of rotisserie.
  - ✓ Wipe off all KOTE product from the sides, rear panels, shaft and disks. Use only approved cleaning products.
  - ✓ Do Not use abrasives on glass - the only approved abrasive on glass is a 3M No.2000 Power Pad
  - ✓ Empty drip pan and rinse unit with water.



# PROCEDIMIENTOS Y PASOS

## DIARIOS DE OPERACION

### Pasos del comienzo

- √ Agregue agua en la bandeja – aproximadamente por la mitad.
- √ Cubra el eje central con papel de aluminio (Solamente para los rostisero “batch”).
- √ Aplique el “KOTE” libremente sobre todos la superficie de metal. NO LO APLIQUE A LOS QUEMADORES DE GAS, PILOTO DE ENCENDIDO, RESISTENCIA O CERAMICAS.
- √ Precaliente el rotisero antes de llenarlo con el producto. Precalentando por 20 minutos es aceptable.
- √ Llene con el producto.
- √ Comience el proceso de cocinar.

### Durante el dia

- √ Supervise el proceso del rotisero.
- √ Al descargar el producto, asegures de limpiar las puertas de cristal para disminuir la adherencia de grasa sobre el cristal.
- √ Supervise el nivel del agua en la bandeja y agregue agua si es necesario.

### Limpiando

- √ Asegures de que la luz y el rotisero estén apagado y que el horno este frío.
- √ Vacíe la bandeja en un envase de basura apropiado.
- √ Re-llene la bandeja con agua jabonosa para limpiar por dentro del rotisero.
- √ Saque todo el “KOTE” de los lados, de los paneles traseros, del eje y los discos. Utilice solamente productos aprobados.
- √ No use abrasivos sobre el cristal – el único abrasivo aprobado en el cristal es el “Power Pad” numero 2000 de 3M.
- √ Vacíe la bandeja y enjuagué la unidad con agua.