



- A: NAC Primer
- B: ECB® Membrane
- C: SubSeal Over Butt-Joint
- D: Outside Corner
- E: Seam Tape
- F: Inside Corner
- G: SubSeal® on Wall

**Bathroom Waterproofing/Sound Control System**  
**ECB® Sheet Membrane/SubSeal® Liquid Membrane**