

HOOD LIGHT MOUNTS

BE SURE TO CHECK ALL PARTS ARE INCLUDED

Left and right mounts , they should be a mirror image of each other.

Each side should consist of lower and upper brackets , stainless bolt, and nut for each side already already installed.



TOOLS NEEDED FOR INSTALL

Wrench or socket to loosen hood hinge bolts.

Allen wrench 5/32" and 7/16" wrench to adjust upper mount angle.

1. LOCATE UPPER HOOD HINGE BOLTS OR NUTS.

Raise the hood and prop open, look where the hood pivots open, this is the hood hinge pivot point. Look above the pivot point and there will be a metal bracket attaching to the hood, there will be 2 bolts or nuts depending on vehicle.

2. INSTALL APOC BRACKETS.

Loosen these bolts (beware if you take them both out the hood can drop and cause damage) only loosen one side at a time enough to slide the bracket you purchased between the bolts and the factory bracket. DO NOT PLACE THE PURCHASED BRACKET BETWEEN THE FACTORY BRACKET AND HOOD. once the Apoc bracket is between the bolt and the hood hinge bracket you can tighten bolts. Now repeat on the other side .



