



Installation Instructions Model E23119-18PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Mark 4 holes on outer slots of bracket for hollow wall anchors
4. Remove bracket from outlet
5. Drill 4 x 1/8" holes and insert hollow wall anchors
6. Reinstall X bracket to outlet and secure bracket to ceiling using 4 screws included into hollow wall anchors
7. Adjust cables to desired length
8. Wire fixture to wires in outlet box. Green wire is for Ground.
9. Install fixture to bracket and tighten 4 screws securely.
10. Install maximum 20 watt G4 xenon bulbs by gently pushing into socket.
11. Install glass shades onto threaded holders and gently tighten. Do not over tighten.

(Caution: Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum 10 minutes before handling)

