SONNEMAN
A WAY OF LIGHT

Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician

A

OFF

OFF

LAMP INSTALLATION AND ASSEMBLY

1. Shut off power to the outlet box. (fig. A)
2. Attach the arms to the posts. To avoid damaging the wires, turn each arm 10 revolutions counter-clockwise before screwing the arm into the post.
3. Determine the height at which the fixture is to be hung. Screw together stem sections to achieve desired length.
4. The cord lengths can be shortened if necessary by cutting cord to length plus six inches.
5. Attach the universal mounting plate to the outlet box, secure with outlet box screws.
6. Make appropriate electrical connections using wire nuts:
   a. Connect the fixture's live wire (black) to the live outlet box wire.
   b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
   c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
   d. Carefully place connections in outlet box.
7. Attach canopy to universal mounting plate, secure with canopy nuts.
8. Install 60W E12 Candelabra base bulbs. (not included)
9. Screw the glass to the socket cups.
10. Restore power to the fixture.

CARE INSTRUCTIONS
Dusting – Use a clean, dry cloth.
Cleaning – To protect the finish,
avoid any harsh abrasives or chemicals.

outlet box

universal mounting plate

outlet box screw

canopy

canopy nut

stem

glass

E12 Candelabra base bulb

socket cup

post

arm

4599

4595