

ASSEMBLY INSTRUCTIONS FOR YOUR
Jonathan Adler
RIO MULTI-GLOBE PENDANT

IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- * If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- * **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton and discard packing materials.
3. Place all parts on a level work surface. Slide hood (L) up cord (K) to expose socket.
4. Install one 60w max, Type A, medium base bulb into socket (P). NOTE: 60w, Type A, medium base bulbs should be installed in the sockets with the larger hoods, and 40w, Type A, medium base bulbs will be installed in the sockets with the smaller hoods.
5. Repeat steps 3-4 for remaining cord sets.
6. Un-thread wing nut (M) from tube (O) and slide it up the cord so it's out of the way.
7. Lift shade bracket (N) from tube (O) and turn it so it's parallel to the socket assembly as shown in Fig. 1. Place the socket assembly and the bracket into glass shade (Q) as shown in Fig.2.
8. Once the parts are inside the shade, slide shade bracket (N) back onto tube (O). Slide wing nut (M) back down the cord and thread it onto tube (O) to secure the position of shade bracket (N). Carefully lift the fixture by the cord as shown in Fig. 3.
9. Slide hood (L) back down the electrical cord until it rests on glass shade (Q).
10. Repeat steps 6-9 for remaining cord sets.
11. Remove mounting plate (B) from canopy (F) by un-threading screws (E). Set screws (E) aside.
12. Lift the mounting plate (B) to the ceiling outlet box. Align the holes in the mounting plate (B) with the ceiling outlet box. Once aligned hold the mounting plate (B) firmly in place and use a pencil to mark the locations of mounting holes (D) on the ceiling.
13. Set the mounting plate aside and drill small holes at the marked locations. Holes should be sized so anchors (I) fit securely inside. Push anchors (I) into the holes.
14. Carefully pull wires from the wall outlet box and thread them through the center hole in mounting plate (B).
15. Attach mounting plate (B) to wall outlet box using screws (C). Thread screws (J) through holes (D) and into wall anchors (I) to secure mounting plate to the mounting surface.
16. Measure the space where the fixture will hang. Determine the desired drop of each globe based on this measurement. NOTE: each globe ships with 11 feet of cord. Each globe in ILLUSTRATION B is labeled with a number (1-5). We suggest the following cord configuration. GLOBE 1: 6.5" of visible cord. GLOBE 2: 14.25" of visible cord. GLOBE 3: 23.75" of visible cord. GLOBE 4: 29.25" of visible cord. GLOBE 5: 38" of visible cord.
17. Once the globe configuration is determined, lock the cords in place inside canopy (F). To do so, loosen screw (G) on wire clamp (H). Guide cord through hole in canopy (F) and slide it to the position of desired drop. Pass cord through clamp (H) and tighten screw (G) as shown in ILLUSTRATION A. If necessary, cut excess cord, leaving 5 or 6 inches of length for wire connections. Repeat step for remaining cord sets.
18. Lift canopy (F) to ceiling outlet box; make proper electrical connections noted in steps 19 - 21. A LICENSED ELECTRICIAN IS RECOMMENDED.
19. Attach ground wire from fixture (green or copper in color) to ground wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
20. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape.
21. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (A) and tightly wrap connection with electrical tape. Gently push wire connections back into the ceiling outlet box.
22. Lift canopy (F) over mounting plate (B). Use canopy screws (E) to attach the canopy to the mounting plate (B).
23. Reconnect main electrical supply at the fuse box/ circuit breaker and test the fixture.

** To clean, use soft cloth only. Do not use any chemical or abrasive cleaners. **

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler RIO MULTI-GLOBE PENDANT

ILLUSTRATION B

