


ASSEMBLY INSTRUCTIONS



Turenne Large Dynamic Chandelier

Item # ARN5262

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

1. Carefully remove all parts from the box.
2. Feed the wires through the rod (F), collar loop (E), canopy (D) and the rod (C).
3. Thread the rod (F) to the connector (G), then thread the rod (C) to the rod (F).
4. Measure the wires then cut, be certain to leave enough length to connect to the wires in the junction box.
5. Strip the insulation on the fixture wires about 5/8".
6. Install the mounting strap (A) to junction box and secure with the mounting screws (B).
7. Wrap the fixture ground wire to the green ground screw on the mounting strap (A) and secure, then connect to ground wire in the junction box using wire nut (I).
IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
8. Connect the fixture ribbed wire (no marking) to the junction box neutral wire with the wire nut (I).
9. Connect the fixture smooth wire (with marking) to the junction box hot wire with the wire nut (I).
DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
10. Install the canopy (D) to the junction box and secure with the collar ring (E).
11. Insert the bulb (not included) into the sockets.
12. Thread the glass shade (J) to the fixture sockets.
DO NOT OVER-TIGHTEN, OTHERWISE GLASS COULD BECOME DAMAGED.
13. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.