

2015-2021 Mustang EMP Rear Seat Delete Installation Instructions

Evans Motorsport Performance Rear Seat Deletes are Made in USA From 3/16" ABS Plastic.

Visit www.EMP.parts and go to the Rear Seat Deletes page to view installation video.

Tools Needed:
Phillips Screwdriver OR
Power Drill/Driver
5/32 and 6mm Drive Bits
15mm Wrench

Hardware Provided:
2 - Black Bolts
2 - Spring Toggle Wings
1 - Black Plastic Rivet
2 - Barrel Nuts



Perform installation at your own risk. We are not responsible for damage to vehicles or injury to persons during installation and/or use of these seat deletes.

1. Place vehicle in park with parking brake on. Double check everything and surroundings to be sure all is safe before starting installation.

2. Pull up on seat bottom to detach from vehicle chassis



3. Pull on seat bottom to disengage from spring and hinge. May need to move fabric to clear spring and hinge and keep from tearing.



4. Repeat for other side then seat bottom should be free and can be removed from car.



5. Using 15mm wrench, remove seat back hinge bolts



6. Large wire bundle will be attached to passenger side hinge bolt. Pull up to remove and push wire bundle out of the way.



7. Pull on seat back release loop to disengage lock and fold seat backs down for both sides.



8. Use 15mm wrench to remove seat back center hinge bolt. This bolt will be used later on the Rear Seat Delete bottom.



9. Pull up on seat back in order to remove seat back center hinge.



10. Pull seat back side hinge straight up off of bolt and remove from car



11. Bring Seat Delete slotted back piece into car and place over seat back brackets.



2015-2021 Mustang EMP Rear Seat Delete Installation Instructions

12. Fit ABS Twist Lock through seat back bracket then twist to lock in place. Make sure they are centered vertically in the bracket.



14. Bring Seat Delete bottom into car and put into place. Lift Seat Delete back to slide bottom underneath.



16. Use barrel nuts to secure rear side holes to existing seat back side hinge bolt. Leave loose for now.



18. When inserting spring toggle wings, be sure to only screw bolt in until just peeking out of wing then turn wings to be facing front and rear of car so they insert properly.



Push down on bolt until spring toggle wings lock in place then tighten slightly.



20. Tighten all hardware.



13. Slide EMP Lock Strap into place like shown.



15. Use seat back center hinge bolt removed earlier to secure center hole to car. Leave loose so you can adjust fit for other holes.



17. Put black bolts into front side holes of Seat Delete bottom then screw spring toggle wings onto black screw on underside of Seat Delete bottom. Be careful to not drop spring toggle wings into hole in car. This step can alternatively be done before pulling Seat Delete bottom into car, just be careful to not damage anything with the loose hardware.



19. Insert bottom section of black plastic rivet into front center hole then push the plastic screw into center. This screw can be unscrewed to remove.

