



FRONT PANNIER RACK INSTALLATION

DESCRIPTION	PART NUMBER	QUANTITY
Nut-6mm	BSHW0008	4
Bolt-5mm x 20	BSHW0020	2
Bolt-5mm x 12	BSHW0012	6
Washer-5mm		16
Rubberized Clamp		4
U Bracket, Large		1
U Bracket, Small		1
Right Side Bag Rack		1
Right Side Bag Rack		1

1. Pinch the rubberized clamps onto the U Brackets.
2. Attach small U bracket to right side of bag rack.
3. Attach large U bracket to right side of bag rack.f
(REPEAT WITH OTHER SIDE)
4. Use the 5mm x 20 bolts to attach rack.

