




## RANS HT REAR RACK INSTALLATION

		
	Parts List	Qty
<p><b>Note:</b> Older bikes with the 1/2" or 5/8" sprint braces will need to use the smaller clamps and extra hardware enclosed.</p> <p><b>V3 Steel and Stratus XP with disk brakes use BPAC0076 rack adapter bars and BPAC0077 rack adapter plates. <a href="#">sold here</a></b></p>	Bolt M5x12	2
	Bolt M5x25	2
	Washer	4
	3/4" clamp	2
	Black washers	8
	5mm nut	2

1. Remove the seat assembly from the bike.
2. Slide Rack over the sprint braces.



3. Attach the rack to the bottom dropouts using 5mm x12 bolt & (2) washers.



4. Slip clamp onto the sprint braces. Using the 5mm x25 bolt & (4) of the black washers, fasten to the corresponding holes on the rack. Tighten with the 5mm nut.

