



Rear Screamer Idler Mod

Goal: To reduce weight by eliminating the lower idler and replacing the idler bracket with a smaller one.



Parts required:

Qty	Parts
1	Rocket Rear Idler Bracket

Tools required:

4mm Hex Driver (Allen)
5mm Hex Driver (Allen)
8mm Wrench
#2 Philips Head Screwdriver
Pliers

Step 1: Disassembly

Loosen the chain retainer to free the chain from the idler assembly. Remove the idler assembly from the bike frame. Lay out the parts as shown in the picture below.



Step 2: Exchange hardware

Move the idler and chain retainer to the Rocket rear idler bracket.



Step 3: Reassembly

Install the new idler bracket on the bike frame using the original hardware. Place the chain over the idler and tighten the chain retainer.



Step 4: Pat your self on the back

Congratulations, you have successfully completed the rear idler mod for your RANS Screamer. Time to go for a ride. Don't forget to show the mod to your friends so they can marvel at your ingenuity.

