



TIMBER CREEK ANNEX

Timber Creek Annex™ Set Up Guide



- 1 Orient tent with zipper door facing away from vehicle.
- 2 Slide the long orange pole through the sleeve above the tent door. Place the ends of the poles in the metal grommet near the back of the vehicle.
- 3 Snap the plastic clips onto the poles.
- 4 Connect the short orange poles to each side of the tent into the metal grommets and snap the plastic clips onto the poles.





TIMBER CREEK ANNEX

5 Place the lower portion of the portal under the vehicle bumper.

6 Connect the 3 interior tent clips.

7 Attach portal clips.



Upper Strap Suggested Attachment Points

- Through rear door to interior handle or headrest
- To exterior Roof Rack

Lower Strap Suggested Attachment Points

- To vehicle wheel well
- Around vehicle tire or to wheel

8 Tighten the exterior portal straps.

9 Stake all 4 corners of the tent. Use black poles and guy lines to set up door awning.

