

Installation

Method 1

Glue Straight on the Panel

Mount the panel on the wall with construction or grab adhesive glue



Method 2

Screw Directly into the Wall

Screw panels directly into the wall studs through the acoustic felt



Method 3

Screw Panels into Wooden Racks

1st- Install underlying wood racks on wall

2nd- Screw panels into wooden racks

- We recommend installing sound-absorbing material like Rockwool between the panel and wood racks. This combination will bring the highest sound absorption.

