

SKULL TOWER RECIPE

WWW.CANDLE-SHACK.COM

CANDLE SHACK

WHAT YOU WILL NEED

152g of Golden Wax 494

8g of Smoke & Mirrors Fragrance Oil

1 x LX8 Wick - 160mm

0.3g 6000/01 Black Dye

Candle Pens (Your Choice Of Colour)

1 x Skull Tower Mould

1 x Pillar Wick Tool

GETTING THE MOULD PREPARED FOR POURING

STEP 1

Find the center of the top skull and mark this with a pen.

STEP 2

Using the Candle Shack pillar wick tool, gently pierce this through the bottom of the mould where you have placed your pen mark.

STEP 3

Thread the tool through the hole you have made in the mould and be sure to push this flat at the bottom. (This ensures to maintain the shape of the top skull head and not create a dent in the top of the poured candle)

STEP 4

Preheating the mould is optional as this doesn't matter if the wax frosts, this adds more spook to your candle.

POURING THE CANDLE

STEP 1

Melt 152g of GW494 wax to 70°c.

STEP 2

Once this has reached temperature add 0.3g (a pinch) of Black bekro dye. Stir this in thoroughly.

STEP 3

Add 8g of Smoke & Mirrors Fragrance oil. Stir the fragrance until the wax and fragrance mixture form a solution.

STEP 4

Pour the mixture slowly and gently into the mould. Ensure not to make this side heavy, allow the mould to fill evenly so this does not tip over as you fill. (If you feel like too many bubbles form on the face area you can use a heat gun to apply some heat to the front of the mould this should allow them to lift to the top, though be sure to do this whilst the wax is just poured into the mould. Or preheat the mould to help the bubbles release themselves.)

STEP 5

Leave for at least 4 hours to dry before removal though best left over night. Once removed from the mould be sure to thread your LX8 wick (160mm) through.

STEP 6

You can decorate this candle with candle pens to make this a little spookier. Unleash your inner artisan.