



# HEART STUDDED CANDLE RECIPE

# CANDLE SHACK

## WHAT YOU WILL NEED

<a href="#">1x 50ml Candle Glass Bowl - Externally Matt White</a>
<a href="#">32.55g of Velvet Peony &amp; Oud Fragrance Oil</a>
<a href="#">432.45g of CS1 Wax</a>
<a href="#">1x Pinch of Bekro Dye - 35/4151 - Rose</a>
<a href="#">3x LX12 Wicks</a>
<a href="#">3x 15mm Adhesive Wick Pads</a>
<a href="#">3x 40x25mm Wick Cores</a>
<a href="#">1x Wax Melt Mould - Lush Hearts</a>

## THE STEP-BY-STEP PROCESS - MAKING THE WAX MELT HEARTS

<b>STEP 1</b> Melt 83.7g of CS1 wax in a double boiler and bring it up to 80°C.
<b>STEP 2</b> Add a pinch of dye and mix well for about a minute.
<b>STEP 3</b> Add 6.3g of Velvet Peony & Oud fragrance and mix well for about a minute.
<b>STEP 4</b> Fill the mould with the mixture and leave it to dry completely for at least an hour.
<b>STEP 5</b> Demould when dry.

## THE STEP-BY-STEP PROCESS - MAKING THE CANDLE

### STEP 6

Clean your glass of any debris.

### STEP 7

Apply stickum to the bottom of LX12 wicks, stick it to the glass evenly spread and thread wick cores on them, making sure they are straight.

### STEP 8

Melt 348.75g of CS1 wax and bring it up to 80°C.

### STEP 9

Add 26.25g of Velvet Peony & Oud fragrance and mix well for about a minute.

### STEP 10

Pour the mixture into the prepared glass.

### STEP 11

Leave the candle to dry for about an hour until it dips.

### STEP 12

Using a flasher or a heat gun melt the top of the candle until you achieve an even surface.

### STEP 13

Place the hearts on top of the candle in your desired pattern and push them gently into the wax so the hearts will be secure.

### STEP 14

Leave the candle to crystallize for 48 hours.

### STEP 15

Trim the wick to 5mm and enjoy!