# Lateral Plungers · smooth, without seal

## 22150.0050



## **Product Description**

To be used for positioning and applying pressure, e.g. during painting and sandblasting.

#### **Material**

#### Body

Aluminium

#### **Spring**

· Stainless steel

### Pin

· Thermoplastic POM, white

#### **Assembly**

Installation by pressing in.

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$ 

 $I_0$  = center distance,

y = workpiece height,

w = workpiece length,

x = coordinate dimension,

s = stroke,

z = stop diameter

Calculation dimension x:

y greater than or equal to  $l_2$  -  $d_2/2$ , then x =

 $d_2/2 - s$ 

or

y smaller than  $l_2$  -  $d_2/2$ , then x =

 $d_2/2 - s - [(l_2 - d_2/2 - y) * 0,123]$ 

#### Characteristic


Light spring load = spring from stainless steel


#### More information

#### **Further products**

• Eccentric Mounting Bushings, for lateral plungers, smooth

## **Drawing**





Erwin Halder KG

### **Order information**

Dimensio	ns d <sub>2</sub>	Spring load  F  max. <sup>1)</sup> ~	Dimension	ns I <sub>2</sub>	Stroke s	Location hole D H8	max.	Ĭ.	Art. No.		
[mm]		[N]	[mm]		[mm]	[mm]	[°C]	[g]			
Pin: Thermoplastic/light spring load											
6	3	10	7	4	1	6	80	0,34	22150.0050		


<sup>1)</sup> statistical average value

www.halder.com Page 1 of 2
Published on: 12.4.2019

## Accessories

	Dimensions d <sub>1</sub>	ă	Art. No.
	[mm]	[g]	
assembly tool			
	6	19	22150.0830

# **Application example**



www.halder.com Page 2 of 2
Published on: 12.4.2019