# Lateral Plungers. with thread, with seal

## 22150.0454



## **Product Description**

To be used for positioning and applying pressure, e.g. during painting and sandblasting. Sealed against chips and dirt.

### Material

### Seal

• CR

### **Body**

· Steel, zinc-plated by galvanization

### **Spring**

Stainless steel

#### Din

Steel, case-hardened, zinc-plated by galvanization

### **Assembly**

Lateral plungers are installed by screwing in by means of a mounting tool.

Formula for calculating the center distance for the mounting hole:

 $I_0 = z/2 + w + x$ 

 $I_0$  = center distance,

y = workpiece height,

w = workpiece length,

w = workpiece length,

x = coordinate dimension,

s = stroke,

z = stop diameter

Calculation dimension x:

y greater than or equal to  $l_2$  -  $d_2/2$ , then x =

 $d_2/2 - s$ 

or


y smaller than  $I_2$  -  $d_2/2$ , then x =


 $d_2/2 - s - [(l_2 - d_2/2 - y) * 0.123]$ 

### Characteristic

Light spring load = spring from stainless steel

## **Drawing**





Erwin Halder KG

## **Order information**

	Stroke	ws	<u>N</u>	I	Art. No.					
d <sub>1</sub>	l <sub>1</sub> -2	Spring load F max. <sup>1)</sup>	d <sub>2</sub>	l <sub>2</sub>	s		max.			
[mm]		[N]	[mm]		[mm]	[mm]	[°C]	[g]		
Pin: Steel/light spring load										
M18 x 1,5	31,5	100	10	16	1,6	16	110	28	22150.0454	


<sup>1)</sup> statistical average value


www.halder.com Page 1 of 2
Published on: 12.4.2019


## Accessories

Dimensions d <sub>1</sub> [mm]	<b>[</b> g]	Art. No.
assembly tool		
M18 x 1,5	137	22150.0822

# **Application example**







www.halder.com Page 2 of 2
Published on: 12.4.2019