



WILDBEAR

Fitting Instructions

From

A.J.S Fabrications

**LS 7599* Transmission Guard
Discovery 2 Td5 / V8**

KIT CONTENTS

1 x Transmission Guard 6 x M8 Rivet nuts
6 x M8x30 Sets
6 x M8 Washers

TOOLS REQUIRED

13mm Socket Drill and bit
Ratchet
13mm Spanner Felt tip pen
Rivet Nut Tool

When working on your vehicle please ensure that it is adequately chocked, and where applicable supported on axle stands. If in doubt please refer to a qualified technician or your nearest Wildbear™ fitting centre.

** We recommend wiping the alloy surface with a soft cloth and WD40 to remove protective film used in manufacture.*

INSTRUCTIONS

- This guard mounts directly under the transmission using the two crossmembers. (One to the front and one to the rear of the transmission. The curve of the guard will logically dictate its position on the cross members.
- It may be necessary to have assistance in supporting the guard to allow the position of the mounting holes to be marked on the crossmembers. Ensure it is held in a central position (left and right).
- After the holes have been marked, drill the holes and fix the rivet nuts into position.
- The guard can then be mounted using the bolts and washers provided. Tighten and check all bolts after fitting.

Thank you for buying and using Wildbear™ Products.

Proudly Designed and Manufactured in the UK

A.J.S Fabrications

Parts and Accessories for Land Rovers



Head office: AJS Fabrications Limited, Unit 26 Crossgate Road, Park Farm Industrial Estate, Redditch, B98 7SN
Tel: +44 (0)1527 830552 Email: enquiries@wildbear4x4.com Web: www.wildbear4x4.com