

N20 Viper Mount Kit Instructions

- 1) Align the plate with two of the included screws. No need to fasten, it's just for alignment.



- 2) Hold the plate in place with your fingers and use the underside of the plate to align/drill two 3/32" holes in the chassis.



- 3) Repeat steps 1 and 2 for other side

- 4) Run the screws in/out of the bottom of the mounts before install. It makes install a lot easier. The holes are slightly undersized on purpose.

- 5) Insert N20 motor into mount. It'll be a little snug.



- 6) Place in chassis and secure from the bottom with supplied screws thru the holes drilled in step 2. Congrats, you're ready to solder on the motor leads and get to fighting. Your install should look similar to the pics below.

