

INSTALLATION GUIDE

Subaru WRX (2022-23)
MUD GUARDS



What's in the package?

- A.** Front mud guard (x2)
- B.** Rear mud guard (x2)
- C.** #8 x 1" (25mm) Phillips flat head screw (x4)
- D.** #8 x 3/4" (19mm) Phillips flat head screw (x6)
- E.** U-nut #8 (x8)
- F.** 1/16" (1.75mm) thick plastic spacer (x2)
- G.** 1/3" (7.75mm) thick plastic spacer (x2)



Required tools

- Phillips screwdriver or Electric drill
- Car Jack
- Wheel nuts removing socket and wrench

Tips before the installation

- Our mud guards should be installed with the logo facing the rear of the car.
- Before installing the provided u-nuts, slightly pry them open with a flat head screwdriver. Doing so will help to prevent scratching the paint when sliding them on.



A. Turn your vehicle's front wheels as much as possible to allow access to the 2 factory fender liner clips shown on the image above.

B. Remove both clips and gently pull on the fender liner to gain access to the fender tabs.



A. Grab 2 of the provided u-nuts(E) and screws(C) that came in the front mud guards package.

C. Slightly pry open each u-nut to facilitate the installation and avoid scratching the paint.

D. Slide the u-nuts on the two fender tabs making sure that the flat face is facing towards the front and that the hole is correctly aligned.

The lower u-nut

must be installed on the fender tab located behind the plastic trim.

D. Push the fender liner back in place.



A. Grab the front mud flap (*FX3D* logo should be facing the rear of the car).

B. Insert both screws(C) through the mud guard's slotted holes. The head of the screws should be resting on the opposite side of the *FX3D* logo.

C. Insert a thicker plastic spacer(G) into the upper screw and one of the thinner spacer(F) into the lower screw.



A. Align and screw both screws into the fender liner. Don't tighten all the way to allow positioning the flaps to your liking.

B. When satisfied with the position, you can tighten both screws completely.
Don't over tighten.

C. Repeat steps 1 to 4 on the other side of the vehicle.

Tips before the installation

We provide size #8 self tapping screws in order to provide a secure installation while not leaving a noticeable hole in the bumper inner lip if you ever remove our mud guards.



A. Jack your car up so you can remove the rear wheel and gain access to the bumper inner lip.

B. Remove the plastic clip shown on the image above.



A. Grab one of the provided u-nuts(E) and slightly pry it open to facilitate the installation and avoid scratching the paint.

D. Pull the black plastic over fender out of the way and slide the u-nut directly on the bumper making sure that the flat face is facing towards the front and that the hole is correctly aligned.

3



- A.** Grab the rear mud flap (*FX3D* logo should be facing the rear of the car).
- B.** Install one of the supplied screws(D) into the middle slotted hole of the mud guard.
- C.** Screw it into the factory hole where you installed the u-nut. Don't tighten all the way to allow for later adjustment.

4



- A.** Rotate the mud guard so that the upper slotted hole aligns with the bumper. Mark the spot with a pen.

The mark should be at 3/8"
(9.5mm) from the inner edge of the black over fender trim.



A. Grab one of the provided u-nuts(E) and slightly pry it open to facilitate the installation and avoid scratching the paint.

B. Slide it behind the black trim and into the bumper inner lip making sure it's aligned with the mark you just made.

C. Install one of the supplied screws(D) into the top slotted hole of the mud guard.

D. Using an electric drill or a screwdriver, screw it into the bumper where the mark was done. Don't tighten all the way to allow positioning the flaps to your liking.



A. When satisfied with the position of the flap, screw one of the supplied screws(D) into the lower plastic trim of the bumper through the lower slotted hole of the mud guard.

B. You can now tighten all screws completely. **Don't over tighten.**

C. Repeat steps 1 to 6 on the other side of the vehicle.