



POLE KIT WITH 1 FLANGE

Includes: 1 Twister, 3 pole sections, 1 flange and 1 baffle

Place a screwdriver into the hole and twist 20" into ground. Loosen the screw on the top of the twister.

Insert the FP9 (longer of the poles, with no swedges) into the twister, tighten the screw to affix to the twister.

Insert the TE14 (14" pole with one swedge) with the swedge going into the top of the FP9.

Affix the collar for the squirrel baffle to the desired height. Recommended height of baffle is 4 feet above ground. Tighten the screws making sure the collar stays level. Slide baffle over pole until it rests on the collar.

Insert the TE20 (last of the pole sections - 22" pole with one swedge) with the swedge going into the top of pole.

Attach flange to feeder with screws included. Put on top of pole kit and tighten thumb screw.

Please call us with questions or concerns at 866-995-BIRD (2473)

