



Slick Willie 3 is the “Evolution of Pump Priming” made by pump operators, for pump operators. Our SW3 has one of the highest viscosities of any pump primer. Higher viscosity means better prime for a better pour.

Features & Benefits:

- Lab created & field tested
- Can be used with any type of pump
- The product is safe to prime into forms, although, we always recommend priming out
- Primer evenly lubricates the inside walls of pipe & hose systems, providing unmatched protection
- Formulation is chemically neutral and safe for the environment
- 60 packs per box & pail

Slick Willie 3

Available sizes	
Box (60 sachets)	6 oz. / 170 gr.
Pail (60 sachets)	6 oz. / 170 gr.
Drum (1000 sachets)	6 oz. / 170 gr.

Instructions

Method #1

- Empty contents of SW3 bag into a bucket.
- Stir well while slowly adding 5 gallons of water
- Let stand for at least 5 minutes until slick.
- Pour SW3 mixture into priming port or hopper just prior to pumping.

Method #2

- Empty contents of SW3 bag into corner of the hopper.
- Stir well while slowly adding water until 5 gallons has been made.
- Let SW3 mixture stand for at least 5 minutes prior to pumping.
- Pour SW3 mixture into priming port or hopper just prior to pumping.

Note -

On hopper styles that allow concrete to get ahead of the prime, start the machine stroking and introduce the concrete slowly to the far side of the hopper to push the SW3 mixture into the discharge pipe, ahead of the concrete.